
2/6/23 (2) 7/8 DIA HOLE 1 1/8 6 3 3/4 15/16 --— 7 1/16

SHIPPING BLOCK (**) \ ELASTOMERIC //	USTING BOLT AND NUT ELASTOMERIC RESTRAINTS
	EQUIPMENT BRACKET
1 3/16	(BY OTHERS)
(TYP)	
7 7/8	
FREE HEIGHT	
	 PLATE WELDED
7 5/8 OPERATING	TOP AND BOTTOM
HEIGHT	SPRING
	RIBBED ELASTOMERIC PAD
3/8	<u> </u>
<u>* </u>	

REV.	DESCRIPTION	DATE	BY

TYPE AMSR-3C-SB SEISMICALLY RESTRAINED SPRING VIBRATION ISOLATORS						
MODEL	RATED LOAD	RATED DEFLECTION	SPRING RATE	COLOR CODE	ALLOWABLE	G RATING ²
MODEL	(LBS) DEFLEC	1			HORIZONTAL	VERTICAL
AMSR-3C-75-SB	75	3.00	25	WHITE	18.7	37.0
AMSR-3C-145-SB	145	2.90	50	LT PURPLE	9.7	19.2
AMSR-3C-215-SB	215	2.59	83	LT BROWN	6.5	12.9
AMSR-3C-315-SB	315	2.37	133	ORANGE	4.4	8.8
AMSR-3C-470-SB	470	2.35	200	DK BROWN	3.0	5.9
AMSR-3C-600-SB	600	2.25	267	DK PURPLE	2.3	4.6
AMSR-3C-860N ¹ -SB	860	2.25	383	ORANGE/RED	1.6	3.2
AMSR-3C-1055N ¹ -SB	1055	2.34	450	DK BROWN/RED	1.3	2.6
AMSR-3C-1165N ¹ -SB	1165	2.25	517	DK PURPLE/RED	1.2	2.4
TABLE NOTES:						

- 1. TWO NESTED SPRINGS YIELD THIS LOAD.
- 2. ALL ALLOWABLE G RATINGS ARE BASED ON HILTI KWIKBOLT TZ WEDGE ANCHORS (OR EQUAL) IN STONE AND AGGREGATE CONCRETE (Fc=3000 PSI)
- 3. RATED LOAD OF ISOLATOR IS STAMPED ON SPRING ASSEMBLY BASE PLATE.



ISOLATOR SELECTIONS		
LOC 1:	LOC 2:	
LOC 3:	LOC 4:	
LOC 5:	LOC 6:	
LOC 7:	LOC 8:	
CUSTOMER EQP'T. TAG:		

NOTE: MATERIAL SHOWN IS FOR (1) SET.

1. ALL DIMENSIONS ARE IN INCHES. INTERPRET PER ANSI Y-14.

SALES ORDER:

- 2. FINISH: HOUSING- ONE COAT BLACK PAINT, SPRING- BLACK PAINT, HARDWARE- ZINC ELECTROPLATE.
- 3. INNER NESTED SPRING, WHEN USED, NOT SHOWN. SEE SPRING TABLE, NOTE 1
- 4. ALL SPRINGS DESIGNED WITH 50% OVER-TRAVEL.
- 5. REFER TO TABLE ABOVE FOR ALLOWABLE HORIZONTAL AND VERTICAL G RATINGS. SEE TABLE NOTE 2.
- ISOLATOR HAS BEEN FACTORY PRE-COMPRESSED A NOMINAL 1/2 INCHES.

PRIOR TO MOUNTING EQUIPMENT, THE INTERNAL VERTICAL RESTRAINT WILL BE AGAINST THE HOUSING TOP PLATE AND THE ADJUSTING NUT WILL BE 1/4" ABOVE THE BLOCK AT THE "FREE HEIGHT." WHEN THE EQUIPMENT IS MOUNTED, THE SPRING WILL DEPRESS AND REST ON THE SHIM AT THE "OPERATING HEIGHT."

RATED DEFLECTIONS ARE WITHIN 25% OF NOMIAL HIGHER DEFLECITIONS ARE ALLOWED IF THEY MEET SPECIFICATIONS S

ISOLATOR HAS (1) SHIPPING BLOCK SHOWN TWICE ON ALTERNATE POSITIONING LOCATIONS.

OTHER MATERIALS, COMPOUNDS, OR FINISHES WITH EQUAL OR SUPERIOR PROPERTIES MAY BE SUBSTITUTED AS THEY BECOME AVAILABLE.



180R-102216

REV.:4

CERTIFIED FOR: JOB NAME: CUSTOMER: CUSTOMER P.O.:

MODEL AMSR-3C-SB 75-1165 LBS. **SEISMIC ISOLATORS** WITH SHIPPING BLOCK 3 INCH DEFLECTION



Houston, TX 77041

NONE 1 OF 2

DRAWING NO.: REVISION 180R-102216 REV.:4 2/6/23 DESCRIPTION


READ INSTRUCTIONS IN THEIR ENTIRETY BEFORE BEGINNING.

FACTORY INSTRUCTIONS

- 1. ISOLATORS ARE SHIPPED FULLY ASSEMBLED AND ARE TO BE SPACED AND ARRANGED IN ACCORDANCE WITH INSTALLATION DRAWINGS OR AS OTHERWISE RECOMMENDED.
- 2. SET ISOLATORS ON FLOOR OR SUB-BASE, ENSURING THAT ALL ISOLATOR CENTERLINES MATCH THE EQUIPMENT MOUNTING HOLES OR SPACE AND ARRANGE ISOLATORS IN ACCORDANCE WITH THE INSTALLATION DRAWING. SHIM OR GROUT AS REQUIRED LEVELING ALL ISOLATOR BASE PLATES AT THE SAME ELEVATION (1/4" MAXIMUM DIFFERENCE IN ELEVATION CAN BE TOLERATED). ISOLATOR BASE MUST REST ON A FLAT SURFACE.
- 3. PRIOR TO MOUNTING EQUIPMENT, INTERNAL STOP "A" WILL BE AGAINST THE TOP PLATE AND WASHER "F" WILL BE APPROXIMATELY 1/4" ABOVE THE SHIPPING BLOCK AT THE "FREE HEIGHT."
- 4. REMOVE SHIPPING BOLT, BUT LEAVE THE SHIPPING BLOCK IN PLACE. ISOLATOR HAS (1) SHIPPING BLOCK SHOWN TWICE ON ALTERNATE POSITIONING LOCATIONS.
- 5. REMOVE EQUIPMENT ATTACHMENT NUT "B" ON ISOLATOR STUD "C" AND PLACE EQUIPMENT ON ISOLATOR WASHER "F". THE EQUIPMENT WEIGHT WILL COMPRESS THE SPRING INSIDE THE HOUSING AND EQUIPMENT BRACKET WILL REST ON THE SHIPPING BLOCK AT THE "OPERATING HEIGHT."
- 6. TURN THE ADJUSTING NUT "D" UNDER THE WASHER COUNTER-CLOCKWISE TO COMPRESS THE SPRING. WHEN THE LOAD IS EQUALIZED, TURNING THE NUT WILL RAISE THE EQUIPMENT UNTIL THE INTERNAL GAP "G-1" IS APPROXIMATELY EQUAL TO THE EXTERNAL GAP "G-2". (I.E. THE EQUIPMENT CAN MOVE UP OR DOWN. THE SAME DISTANCE IN A SEISMIC EVENT).
- 7. THE ADJUSTING PROCESS SHOULD BE DONE GRADUALLY ON ALL ISOLATORS UNTIL THE EQUIPMENT WEIGHT IS NO LONGER RESTING ON THE SHIPPING BLOCKS.
- 8. REPLACE ISOLATOR ATTACHMENT NUTS "B" ON ADJUSTING BOLTS "C" TO SECURE MACHINE LEGS TO ISOLATORS. HAND TIGHTEN WHERE THERE IS FIRM CONTACT BETWEEN THE NUT AND EQUIPMENT. (HAND TOOLS MAY BE USED.) THEN TIGHTEN THE NUT AN ADDITIONAL 1/3 TURN. REPLACE SHIPPING BOLT AND HAND-TIGHTEN WHERE THERE IS FIRM CONTACT BETWEEN THE BOLT AND EQUIPMENT BRACKET. TOOLS MAY BE USED TO BRING THE BOLT AND METAL COMPONENTS INTO CONTACT. FOLLOWING CONTACT, TIGHTEN THE **BOLT ANOTHER 1/3 TURN.**

FIELD INSTRUCTIONS

- 1. SHIPPING BLOCK FIXES THE EQUIPMENT AT THE OPERATING HEIGHT. AFTER EQUIPMENT IS INSTALLED AT ITS FINAL LOCATION, REMOVE SHIPPING BOLT. IF THE BLOCK WILL NOT SLIDE OUT, TURN ADJUSTING NUT COUNTER-CLOCKWISE UNTIL EQUIPMENT DEAD LOAD IS NO LONGER RESTING ON SHIPPING BLOCK. REMOVE SHIPPING BLOCK AND DISCARD.
- 2. THRUST RESTRAINTS MUST BE ADDED TO THE FAN IF THE TOTAL FAN STATIC PRESSURE IS 2" W.G. OR GREATER.



OTHER MATERIALS, COMPOUNDS, OR FINISHES WITH EQUAL OR SUPERIOR PROPERTIES MAY BE SUBSTITUTED AS THEY BECOME AVAILABLE.



CERTIFIED FOR: JOB NAME: CUSTOMER:

CUSTOMER P.O.:

SALES ORDER:

MODEL AMSR-3C-SB 75-1165 LBS. SEISMIC ISOLATORS WITH SHIPPING BLOCK 3 INCH DEFLECTION



THE POWER OF TOGETHER' Bloomingdale, NJ 07403 Houston, TX 77041

SCALE :	
NONE	Member
SHEET:	····-VISCM
2 OF 2	
DRAWING NO.:	REVISI

DATE